

1. Gniazda wejścia/wyjścia
Moc znamionowa 37Wh/3.7V
Pojemność 10000mAh
USB Type C wejście 5V-2A
USB 1 A wyjście 5V-2A
USB 2 A wyjście 5V-2A

2. Celem sprawdzenia poziomu naładowania akumulatora naciśnij przycisk. Ilość diod/cyfra na ekranie pokaże poziom baterii.
3. Jeżeli produkt posiada funkcję tzw. szybkiego ładowania in/out, jedna z diod podczas szybkiego ładowania świecić będzie innym kolorem niż pozostałe. Jeżeli akumulator posiada ekran, podczas szybkiego ładowania in/out pojawi się ikona.
4. Aby skutecznie naładować urządzenie należy podłączyć kabel z odpowiednią końcówką do jednego z gniazd „wejścia”. Aby skutecznie naładować odbiornik np. telefon, należy połączyć kabel ładowania z jednej strony do jednego z gniazd „wyjścia” akumulatora, natomiast drugą wtyczkę kabla do gniazda urządzenia, które chcemy naładować.

INFORMACJA DOTYCZĄCA BEZPIECZEŃSTWA I ŚRODKÓW OSTROŻNOŚCI :

1. Przenośny powerbank posiada wysokiej jakości ogniwo baterijne, które gwarantuje wygodne i długie użytkowanie.
2. Sugeruje się, aby użytkownik używał standardowego zasilacza o napięciu wyjściowym DC 5V.
3. Jeżeli występuje zjawisko puchnięcia baterii, widąc wypukłość na obudowie, należy bezwarunkowo zaprzestać użytkowania produktu i natychmiast skontaktować się z serwisem.
4. Nie rzucać urządzenia, nie otwierać obudowy, nie demontować elementów obudowy, nie narażać urządzenia na przebiecie. Nie narażać na działanie ognia, wysokich temperatur oraz wilgoci i wody.
5. Zaleca się okresowe ładowanie urządzenia (co najmniej raz na 4 miesiące), aby zachować żywotność ogniw bateryjnych.

Ostrzeżenie. Należy postępować zgodnie z powyższymi instrukcjami bezpieczeństwa, w przeciwnym razie urządzenie może spowodować pożar, wybuch bądź inne szkody.

1. Input/output sockets characteristics

Rated power 37Wh/3.7V
Capacity 10000mAh
USB Type C input 5V-2A
USB 1 A output 5V-2A
USB 2 A output 5V-2A

2. To check the battery level, press the button on the device. Number of LEDs/ Digit on the screen will show the battery level.
 3. If the product has the function of the so-called fast charging in/out, one of the diodes during fast charging will glow with a different color than the others. If the battery has a screen, the fast charging icon will appear during fast in/out charging.
 4. To effectively charge the device, connect the cable with the appropriate end to one of the "input" sockets.
- In order to effectively charge the receiver, eg a telephone, connect the charging cable on one side to one of the battery "output" sockets, and the other end of the cable to the socket of the device that you want to charge.

SAFETY NOTICE, CAUTION:

1. The portable powerbank has a high-quality battery cell that guarantees comfortable and long use.
2. It is suggested that the user use a standard DC 5V power supply.
3. If there is a battery swelling phenomenon and you can see a bulge on the case, stop using the product unconditionally and contact the service center immediately.
4. Do not throw the device, open the housing, do not disassemble the housing elements, do not expose the device to puncture. Do not expose to fire, high temperatures, moisture and water.
5. It is recommended to periodically charge the device (at least once every 4 months) to maintain the life of the battery cells.

Warning. Be sure to follow the safety instructions above, otherwise the device may cause fire, explosion or other damage.